METALS

## SPECIAL OXIDE PILOT PLANT


DEMONSTRATE YOUR PROCESS WITH ANDRITZ SPRAY ROAST TECHNOLOGY



# Experts in process development

Are you looking for a closed loop leaching process? Do you have unused metal ore fractions or solutions? Together we develop your process and prove technical feasibility on a pilot scale. We produce valuable metal oxide samples for product demonstration and further investigation. Benefit from our expertise!





### FEATURES

- Spray roast acid regeneration pilot plant
- Test production of metal oxides (Fe, Mg, Co, Ni, Mn, Al, special and mixed oxides)
- + Regeneration of HCl,  $HNO_3$  and HF
- Modular design to adapt for your specific test requirements
- Capacity: 40-70 l/h of metal solution (typical 100g Me/l)
- Plant location: St. Pölten, Austria



## DECOMPOSITION IN THE REACTOR (EXAMPLE)

Material	In	Out
Iron	2 FeCl <sub>2</sub> + 2 H <sub>2</sub> O + ½ O <sub>2</sub>	Fe <sub>2</sub> O <sub>3</sub> + 4 HCl
Nickel	$\text{NiCl}_2 + \text{H}_2\text{O}$	NiO + 2 HCl
Cobalt	3 CoCl <sub>2</sub> + 3 H <sub>2</sub> O + ½ O <sub>2</sub>	Co <sub>3</sub> O <sub>4</sub> + 6 HCl




Processed feed solutions

ESTABLISHED TECHNOLOGY FROM STEEL PICKLING PROCESS FOR MAGNESIUM OXIDE, NICKEL OXIDE, COBALT OXIDE, ALUMINUM OXIDE, MIXED OXIDES, AND OTHERS

HYDROCHLORIC ACID REGENERATION PLANTS Over 200 plants built Spray roaster or fluid bed type Up to 20,000 l/h single plant capacity

**PYROMARS: MIXED ACID REGENERATION PLANTS (HNO<sub>3</sub> + HF)** 22 plants built Special roaster type Up to 8,500 l/h single plant capacity

**METAL OXIDE PLANTS** 18 plants built Special roaster type



3



## ENGINEERED SUCCESS FOR FLAT PRODUCT PROCESSING

#### **AUSTRIA**

ANDRITZ AG p: +43 50805 55325 carbon.regeneration@andritz.com

ANDRITZ.COM/METALS



All data, information, statements, photographs and graphic illustrations in this leaflet are without any obligation and raise no liabilities to or form part of any sales contracts of ANDRITZ AG or any affiliates for equipment and/or systems referred to herein. © ANDRITZ AG 2019. All rights reserved. No part of this copyrighted work may be reproduced, modified or distributed in any form or by any means, or stored in any database or retrieval system, without the prior written permission of ANDRITZ AG or its affiliates. Any such unauthorized use for any purpose is a violation of the relevant copyright laws. ANDRITZ AG, Stattegger Strasse 18, 8045 Graz, Austria. ME-ARP\_Pilotplant\_EN\_2019

